

BLADE II™ PRINTER OPTIONS

Print features available for the *BLADE ii™* wood processing system.

Overview of Printer Options

- A** Standard printer included with every saw, uses 1 print head to print standard print fields (text) on front face.
- B** Uses two print heads to print standard print fields, joint and plate information, and joint alignment marks on face-up (on assembly tables) side of board.
- C** Same as A, plus a 2nd print head to print on top edge of board.
- D** Same as B, plus a 3rd print head to print on edge of board.
- E** AGS+ Advanced print heads for higher definition printing, plus plate outlines and basic graphics on face-up side.
BEST ROI FOR TRUSSES!
- F** AGS+ Same as E, plus a 3rd print head to print on edge of board.
BEST ROI FOR WALLS!

Compare and Contrast Printer Options

	Front	Rear	Edge	Front	Rear	Edge	Face-Up Side					Front	Rear	Edge
	# of Valves			Standard Print Fields [^]			Joint #	Alignment Marks [*]	Plate Size	Plate Outline	Graphic	Wall Marks		
A	16	0	0	X										
B	16	7	0	X	X		X	X	X					
C	16	0	7	X		X						X		X
D	16	7	7	X	X	X	X	X	X			X		X
E (AGS+)	32	32	0	X	X		X	X	X	X	X			
F (AGS+)	32	32	7	X	X	X	X	X	X	X	X	X		X

[^] Default Standard Print Fields are truss name, quantity, and description, but many other text fields can be chosen from.

^{*} Joint Alignment Marks can be moved toward the top or bottom edge of the boards so they are closer to the joint.